

ISTRUZIONI POSA PER RIVESTIMENTI MURALI CON SUPPORTO IN TESSUTO NON TESSUTO (TNT)

ATTENZIONE:

Prima di eseguire la posa dei rivestimenti murali preparare le pareti su cui si dovrà montare il rivestimento.

Il posatore deve assicurarsi che il retro del parato al momento dell'applicazione sia pulito e non abbia residui di perline di vetro, sabbia ecc...

Si consiglia, se il parato è di un colore scuro, di dare al muro una mano di vernice dello stesso colore e procedere, dopo l'asciugatura della tinta murale, alla messa in opera.

Condizioni di posa

Lavorare in ambiente secco e con una temperatura di circa 16° evitare qualsiasi corrente d'aria. In periodi umidi e freddi riscaldare i locali prima, durante e dopo la posa.

La posa in ambienti umidi, freddi, ventilati o troppo caldi può generare restringimenti della carta, macchie o grinze, dei quali non possiamo essere ritenuti responsabili.

Preparazione del muro

I muri devono essere sani, secchi, puliti, piani e leggermente assorbenti. E' possibile utilizzare una carta fodera. Sui muri tinteggiati, lavare, risciacquare, infine carteggiare per ridare la porosità originale al supporto.

Preparazione dei teli

Assicurarsi della conformità del rivestimento PRIMA DI USARLO.

Manipolare con molta cura i teli per evitare la formazione di false pieghe. Le carte sono lavorate A MANO, si possono pertanto presentare delle lievi differenze di tono.

Scegliere i rotoli più simili per ogni muro prima di tagliare.

Posa rivestimento murale :

Utilizzare colla tipo Metylan Special seguendo le istruzioni indicate sulla confezione. **Distribuire SUL MURO LA COLLA** per una superficie di circa due teli.

Durante la posa in parete, rispettare il numero di sequenza dei rotoli se indicato ed il loro verso. Posare il primo telo a piombo, distendendolo con una spazzola a setole morbide evitando il contatto con il bordo. Posare il secondo telo seguendo la procedura del primo accostandoli perfettamente. Con la spazzola a setole morbide distendere entrambi i teli in corrispondenza della giunta. **Pulire le eventuali fuoriuscite di colla con una spugna inumidita SOLO QUANDO IL RESIDUO DI COLLA E' SECCO (36/48 ORE)**

AVVERTENZE

Le eventuali leggere differenze di tono tra i rotoli sono il risultato della lavorazione "a mano" e sono caratteristica di un prodotto di alto artigianato tradizionale e non possono essere causa di reclamo.

Si raccomanda la massima cura e attenzione poiche' il parato e' delicato. La posa di più di tre teli equivale all'accettazione del prodotto.

HANGING INSTRUCTIONS FOR WALLCOVERINGS NON WOVEN BACK

ATTENTION:

Before hanging the wallpaper please all surfaces.

The applicator must make sure that the back of the wallpaper is clean, without dirt or dust etc.

We recommend painting the wall (at least between the joints) in a dark colour, if the wallpaper is a dark colour. Work in a dry room at a minimum temperature of 16°C. Avoid any draught. If working in a humid or cold environment, heat the rooms before, during and after hanging. Hanging in humid, cold or airy places can make the wallpaper shrink, crumple or stain. No liability will be accepted for these inconveniences.

Preparation of the surface

Surfaces must be in good conditions, dry, clean, smooth and slightly absorbent. A lining paper can be used for very absorbing walls.

Before hanging on a painted wall, clean it with a damp cloth. Sandpaper can be used in order to bring back the original porosity of the surface.

Preparation of the lengths

Make sure the wallpapers are in compliance with your needs BEFORE HANGING. Handle the wallpaper with care to avoid wrinkles.

Since wallpapers are hand-made, slight differences of tone and texture might occur. Choose the most similar rolls for each wall cutting the lengths.

Hanging the lengths

Use adhesive type "Methylan Special" and follow the manufacturer's instructions for the preparation.

Eventually mix it with adhesive type "Ovalit" following the manufacturer's instructions. Apply the glue on the wall with a roll (or brush), covering a surface of 2-or 3 lengths.

When apply the wallpaper to the wall, follow the sequence numbers of the rolls, if indicated and the direction indicated on each single roll.

Hang the first length of wallcovering with a lead-line gently smooth it with, a soft brush, avoiding contact with the edges. Hang the second length following the same process, joining both lengths perfectly. **Gently smooth the joints with a soft brush. Glue stains can be removed by means of a damp cloth ONLY WHEN THE GLUE RESIDUE IS DRY (36/48 HOURS)**

WARNING

Slight tone differences of tone and texture between the rolls might occur and are the result of a hand finished product.

These are characteristics of a highly traditional handcrafted product, and no claims can be accepted. This is a delicate product and needs to be treated as such.

This product is considered to be accepted after hanging more then three lengths.

 12 0497/CPR	
AGENA s.r.l. Corso Unione Sovietica, 225 10134 TORINO Telefono + 39 - 011.31 71 919 Fax + 39 - 011 3172000 e-mail: agena@agenagroup.it	EN 15102:2007/A1:2011 AGENA W1
Uso: Rivestimenti murali decorativi	
Reazione al fuoco	B-s2, d0 Su sottostruttura Euroclass A1
Rilascio di formaldeide	Passa
Rilascio di altre sostanze pericolose: metalli pesanti ed elementi specifici	Bario (< 5 mg/kg) Selenio (< 5 mg/kg) Passa
di Vinil cloruro monomero (VCM)	Passa
Assorbimento del suono	NPD
Resistenza termica	NPD



HANGING INSTRUCTIONS FOR WALLCOVERINGS NON WOVEN BACK

ATTENTION:

Before hanging the wallpaper please all surfaces.

The applicator must make sure that the back of the wallpaper is clean, without dirt or dust etc.

We recommend painting the wall (at least between the joints) in a dark colour, if the wallpaper is a dark colour.

Work in a dry room at a minimum temperature of 16°C. Avoid any draught.

If working in a humid or cold environment, heat the rooms before, during and after hanging.

Hanging in humid, cold or airy places can make the wallpaper shrink, crumple or stain. No liability will be accepted for these inconveniences.

Preparation of the surface

Surfaces must be in good conditions, dry, clean, smooth and slightly absorbent. A lining paper can be used for very absorbing walls.

Before hanging on a painted wall, clean it with a damp cloth.

Sandpaper can be used in order to bring back the original porosity of the surface.

Preparation of the lengths

Make sure the wallpapers are in compliance with your needs BEFORE HANGING. Handle the wallpaper with care to avoid wrinkles.

Since wallpapers are hand-made, slight differences of tone and texture might occur.

Choose the most similar rolls for each wall cutting the lengths.

Hanging the lengths

Use adhesive type "Methylan Special" and follow the manufacturer's instructions for the preparation.

Eventually mix it with adhesive type "Ovalit" following the manufacturer's instructions.

Apply the glue on the wall with a roll (or brush), covering a surface of 2- or 3 lengths.

When apply the wallpaper to the wall, follow the sequence numbers of the rolls, if indicated and the direction indicated on each single roll.

Hang the first lenght of wallcovering with a lead-line gently smooth it with, a soft brush, avoiding contact with the edges.

Hang the second length following the same process, joining both lengths perfectly.

Gently smooth the joints with a soft brush. Glue stains can be removed by means of a damp cloth ONLY WHEN THE GLUE RESIDUE IS DRY (36/48 HOURS)

WARNING

Slight tone differences of tone and texture between the rolls might occur and are the result of a hand finished product.

These are characteristics of a highly traditional handcrafted product, and no claims can be accepted.

This is a delicate product and needs to be treated as such.

This product is considered to be accepted after hanging more then three lengths.

 12 0497/CPR	
AGENA s.r.l. Corso Unione Sovietica, 225 10134 TORINO Telefono + 39 – 011.31 71 919 Fax + 39 - 011 3172000 e-mail: agena@agenagroup.it	EN 15102:2007/A1:2011 AGENA W1
USO: Rivestimenti murali decorativi	
Reazione al fuoco	B-s2, d0 Su sottostruttura Euroclass A1
Rilascio di formaldeide	Passa
Rilascio di altre sostanze pericolose:	
metalli pesanti ed elementi specifici	Bario (< 5 mg/kg) Selenio (< 5 mg/kg)
di Vinil cloruro monomero (VCM)	Passa
Assorbimento del suono	NPD
Resistenza termica	NPD

